LANDSCAPE FABRICS





Instructions for use

- Strim vegetation to ground level ensuring there are no fibrous roots which could penetrate the membrane
- For badly affected areas use a suitable weed killer
- Weedban Ultra must be covered with 50mm layer of mulch, aggregate or artificial grass for longer life
- Overlaps need to be 100-150mm wide
- Secure edges with geotextile pegs or dig a 150-200mm vertical trench along the side of the membrane, tuck the membrane edges into this and backfill

Cardboard dump bins also available, please contact us for more information.





www.johngeorge.co.uk www.henryshaw.co.uk

JG: 0118 941 1234 HS: 0121 772 5561